

Ver.1.1

Diagonal 11.1 mm (Type 2/3) CMOS solid-state Image Sensor with Square Pixel for Color Cameras

Description

The IMX546-AAQJ is a diagonal 11.1 mm (Type 2/3) CMOS active pixel type solid-state image sensor with a square pixel array and 8.13 M effective pixels. This chip features a global shutter with variable charge-integration time. This chip operates with analog 3.3 V, 2.9 V, digital 1.1 V, and interface 1.8 V quadruple power supply. High sensitivity and low dark current characteristics are achieved.

(Applications: FA cameras, ITS cameras)

Features

- ◆ CMOS active pixel type dots
- ◆ Built-in timing adjustment circuit, H/V driver and serial communication circuit
- ◆ Global shutter function
- ◆ Input frequency 37.125 MHz / 74.25 MHz / 54 MHz
- ◆ Number of recommended recording pixels: 2840 (H) × 2840 (V) approx. 8.06 M pixels
- ◆ Readout mode
 - All-pixel scan mode
 - Vertical / Horizontal 1/2 Subsampling mode
 - ROI mode
 - Vertical / Horizontal - Normal / Inverted readout mode
- ◆ Readout rate
 - Maximum frame rate in
 - All-pixel scan mode: 8 bit 91.0 frame/s, 10 bit 81.6 frame/s, 12 bit 60.8 frame/s
- ◆ Pulse Output Function
 - The monitor output for Exposure period
 - Programmable pulse output
- ◆ 8-bit / 10-bit / 12-bit A/D converter
- ◆ CDS / PGA function
 - 0 dB to 24 dB: Analog Gain (0.1 dB step)
 - 24.1 dB to 48 dB: Analog Gain: 24 dB + Digital Gain: 0.1 dB to 24 dB (0.1 dB step)
- ◆ I/O interface
 - SLVS (2 ch / 4 ch / 8 ch switching) output (594 / 297 / 891 / 445.5 Mbps per ch)
 - SLVS - EC (1 Lane / 2 Lane) output (4.752 / 2.376 / 1.188 Gbps per Lane)
- ◆ Recommended lens F number: 2.8 or more (Close side)

Pregius S

* Pregius S is a registered trademark or trademark of Sony Group Corporation or its affiliates. Pregius S is a global shutter sensor technology for active pixel-type CMOS image sensors. By stacking the signal processing on the back illuminated type CMOS Image Sensor it realizes small chip size and high sensitivity, whilst using the high picture quality global shutter pixel technology of Pregius.

Sony reserves the right to change products and specifications without prior notice.

"Sony", "SONY" logo are registered trademarks or trademarks of Sony Group Corporation or its affiliates.

Device Structure

◆ CMOS image sensor			
◆ Image size	Diagonal 11.1 mm (Type 2/3)	Approx. 8.13 M pixels	All-pixel
◆ Total number of pixels	2856 (H) × 2912 (V)	Approx. 8.31 M pixels	
◆ Number of effective pixels	2856 (H) × 2848 (V)	Approx. 8.13 M pixels	
◆ Number of active pixels	2856 (H) × 2848 (V)	Approx. 8.13 M pixels	
◆ Number of recommended recording pixels	2840 (H) × 2840 (V)	Approx. 8.06 M pixels	All-pixel
◆ Unit cell size	2.74 μm (H) × 2.74 μm (V)		
◆ Optical black	Horizontal (H) direction: Front 0 pixel, rear 0 pixel Vertical (V) direction: Front 64 pixels, rear 0 pixel		
◆ Package	230 pin LGA	20.0 mm (H) × 16.8 mm (V)	

Image Sensor Characteristics

(Tj = 60 °C)

Item		Value	Remarks
Sensitivity	Typ.	8620 Digit/lx/s	
Saturation signal	Min.	4094 Digit	

Basic Drive Mode

Drive mode	Recommended number of recording pixels	Maximum frame rate [frame/s]	Output interface	ADC [bit]
All pixel	2840 (H) × 2840 (V) approx. 8.06 M pixels	87	SLVS 8 ch	8
		91	SLVS – EC 2 Lane	
		71	SLVS 8 ch	10
		81	SLVS – EC 2 Lane	
		60	SLVS 8 ch	12
		60	SLVS – EC 2 Lane	
Vertical / Horizontal 1/2 subsampling	1420 (H) × 1420 (V) approx. 2.01 M pixels	176	SLVS 8 ch	8
		176	SLVS – EC 2 Lane	
		168	SLVS 8 ch	10
		168	SLVS – EC 2 Lane	
		118	SLVS 8 ch	12
		118	SLVS – EC 2 Lane	

